


## Flat Gate Closer Installation

- 1.** Place gate closer 1/2" to 1" from edge of gate and between the hinges with the spring arm against the post.


*If hinges are on the right side of your gate then flip the gate closer over so the spring arm is on the top.*

*Big screws are self tapping and do not need a pilot hole if using a power driver. Drill pilot holes if you are using a manual screw driver.*




- 2.** Install Gate Closer using four big screws, if your gate is not very thick you may need to add a block on the back side.

*You can also use bolts and nuts if you are installing on a vinyl gate or if your gate is thinner than the screw length.*



- 3.** Install the protector plate using two small screws



- 4.** Gate closing tension adjustment.

*Use 3/4" wrenches or socket and loosen 3/4" nut, then twist bolt towards spring arm to increase tension or away from spring arm to lessen tension, while holding desired tension on bolt, retighten nut, after nut is tight test the gate.*

*You can also watch the installation video on our website at: [www.gateshut.net/gate-closer-videos](http://www.gateshut.net/gate-closer-videos)*

